#### WARRANTY

Bowmar/ALI, Inc. warrants to the purchaser of this new Bowmar Calculator that if the machine or any part thereof in the judgment of Bowmar is proven to be defective in material or workmanship within one year from date of original. purchase, such defects will be repaired or replaced (at the Company's option) free of charge for parts and labor.

This warranty does not apply to any product which has been damaged by accident or which has been misused, abused, altered, or repaired by anyone other than Bowmar.

This warranty is in lieu of all other warranties expressed or implied, and no person is authorized to assume for Bowmar any other liability in connection with the sale of this product.

To obtain repairs, the Calculator should be delivered, prepaid, to Bowmar/ALI, Inc. at address shown below. In-warranty units will be returned postage prepaid.

> SET MARYALL NC: SET MARY STREET ACTON, MASS. 01720

# Five Function

## Eight Digit Electronic Calculator

### 

Instructions for use

#### INTRODUCTION

Your Bowmar Brain is light enough and small enough to be used in one hand, but it provides a standard keyboard and a light emitting diode (LED) display that is easily read at home or in the office.

The eight digit display and the full floating decimal allow the calculation of any problem without sacrificing accuracy.

Whether you want to solve engineering or budget problems, your calculator has the ability with features such as clear entry, automatic squaring, and an omni-constant that will perform integer powers, reciprocals and fractions as well as chain and mixed calculations.

The battery will recharge in seven hours and operate the calculator for five, but with the charger/power supply no useful time will be lost since it operates the calculator while charging it.

We suggest that this Instruction Manual be read with the calculator in hand. Performing the operations as you read them will increase your familiarity with them. For a quick reference, an outline of operations is on the back of the calculator.

#### OPERATION

#### AC Operation:

Connect the Charger unit to any standard 120 Volt electrical outlet and plug the connector into the Calculator. After the above connections, the power switch may be turned on and operation started. (While connected to AC, the internal batteries are automatically charged whether the power switch is "ON" or "OFF".)

#### **Battery Operation:**

Disconnect the Charger cord and turn the power switch "ON". With normal use a full battery charge can be expected to supply about 5 hours of working time.

NOTE: When the low battery indicator (L) on the display is lighted, do not continue battery operation. This indicates need for a battery charge.

#### **Battery Charging:**

Simply follow the same procedure as in AC operation. The Calculator may be used during the charge period if desired. In order to fully charge a battery which has been completely discharged, 7 hours is required. In most cases, an overnight charge should be adequate if the batteries have not been fully discharged.

NOTE: Although no damage will result from prolonged periods with the Charger connected, it is advisable to remove the Charger cord when the Calculator is not in use after a full recharge cycle.

**CAUTION:** To avoid possible damage, use only the charger provided with the calculator.

-



-

#### **CONTROLS & INDICATORS**

1.	"ON" Switch	Turns Calculator "ON" & "OFF".
2.	% Key	Completes a per cent operation and conditions a discount or markup operation.
3.	C Key	Clears the Calculator and the display of all numbers.
4.	= Key	Completes multiply or divide operation.
5.	Х Кеу	Enters a "multiply" command.
6.	🤟 Key	Enters a "divide" command.
7.	Key	Adds the entered number or carries out a previously entered markup operation.
8.	Key	Changes the sign of a multiply or divide answer. Subtracts the entered number or carries out a previously entered discount operation.
9. 10	Key Keys	Enters a decimal point. Enter digits of a number (limit 8 digits).
11	-	Charger cord socket.
12	•	Charger/Power Supply.
•		

.

1

#### Indicates a calculation result Overflow that contains more than eight Indicator digits. Appears as Low Battery Warns of need for battery charge during battery Indicator operation. Appears as Activated by the key for Minus Sign operations with negative Indicator numbers. Appears as Decimal Point Automatically appears to the right of any number entered, Indicator unless inserted in another sequence by use of the Decimal key. With fractional numbers, it will be preceded by a zero.

. .

والمريح والمراجع والمراجع والمرجع والمراجع والمراجع

#### **BATTERY NOTES**

- 2014年前,前期前期的周期的周期的周期的周期的周期的周期的周期,在1914年前,前期前期前期间的同时,1914年,1915年,1915年,1915年,1915年,1915年,1915年,1915年,1915年,191

- With normal use at room temperature, a full battery charge can be expected to supply about 5 hours of accumulated working time.
- 2. The Calculator may be used while its battery is charging.
- 3. Batteries that have been neither used nor charged for as long as 2 or 3 months will suffer substantial loss of operating time through a tendency to self-discharge. As a general rule, batteries lose about 1% charge per day due to self-discharge, at normal temperatures.
- 4. For optimum performance and long life: a. Alternate frequently between Battery and
  - AC power.
  - b. Operate at or near normal room temperatures.
  - c. Charge as soon as possible upon appearance of the Low-Battery indicator.
- 5. Recharge time is 7 hours for a fully discharged battery, with the calculator off.
- 6. The Low-Battery indicator is designed to appear as soon as battery voltage drops to the lowest value that will support optimum performance of the Calculator. Should further discharge occur, through continued operations or self-discharge, the Low-Battery indicator may fail to appear. Do not continue to operate on batteries when this condition is noted, or a damaged battery may result.
- As a general rule, if improper operation occurs, first try the Calculator with its charger connected. If operation is then normal, this indicates the batteries are low.
- 8. Do not store the unit in high temperature areas such as the top of radiators or the rear deck of automobiles exposed to the sun. The Calculator will operate satisfactorily over an ambient temperature range of 0 to 50C (32 to 122F) and relative humidity to 95%.

#### INSTRUCTIONS

#### **1. To clear (erase)**

- A. Touch the c key twice
- B. Cleared display will be:

2. To enter (write a number)

Example: enter 123.45

- A. First, clear by touching c twice
- B. Then touch number and decimal keys for 123.45 one at a time. Always start with the left hand digit and progress from left to right.
   Display will then be:

#### 3. To clear an incorrect entry

•

Example: 48+ 12 is your calculation

- A. You have already entered 48 Display is:
- B. You now touch the + key Display will be:



123.45

60

4

÷

.

والمحاج والمحاج والمحاجب والمعتق بتهم والمتنان والمحاج والمتحاج والمعتم والمحموم والمحموم والان

C.	Then you enter 13 by mistake The display is: 13. A mistake!
	Ft IIIIGtaile
D.	To clear 13, touch the c key once Display will be:
E.	Then enter '12'
	Display will be:
	F L.
F.	Finally, touch the key for answer Display will be:
	60.
No	te: Use during, or immediately after entry of a number to clear entry. Use of key when a result is displayed without overflow clears the result.

+

\*

.

-

يحجم والمراجع والمحجون والمحجور والمحجور

1

#### CALCULATIONS 1. ADDITION

Example #1: To calculate 16.39 + 9.83 =Do these steps display will be

a. Touch C twice	
b. Enter 16.39	16.39
c. Touch	16.39
d. Enter 9.83	9.83
e. Touch 🛃 Answer	
Example #2: To calculate 16 + 9 + 8.3 Do these steps	+ 4.1 = display will be
a. Touch C twice	O.
b. Enter 16	
c. Touch +	16.
d. Enter 9	
e. Touch +	And the form
Enter 8.3	
g. Touch	the stage of the s
n. Enter 4.1	4.1
Touch Answer	

المريان المتحديد ومرجر ومراجع ومحدور والمتحد ومحار والمحاو



**1**-

Example #3: To calculate 62 — 82 + 10 Do these steps	— <b>40</b> = display will be
a. Touch c twice	
b. Enter 62	52.
c. Touch +	62.
d. Enter 82	82.
e. Touch	20.
f. Enter 10	10.
g. Touch +	10.
h. Enter 40	A.
i. Touch – Answer	
3. MULTIPLICATION	
Do these steps	display will be
a. Touch C twice	0.
b. Enter 29.32	29.32
c. Touch X	29.32
d. Enter 56.5	56.5
e. Touch 🚍 🛛 Answer	1656.58

.

1.1

-

.

÷ 4

•

Control of

يحادثه فالجاديون ولارد والأرا



<sup>. . .</sup> 

١.

\*



#### 27. e. Touch 🕂 f. Enter 9 g. Touch Answer Example #3: To calculate $181 \div 15 =$ **Use of Omni-Constant** 96 ÷ 15 = 117 ÷ 15 = display will be Do these steps twice Sec. 6 a. Touch C b. Enter 181

والمتاجرة المراجع والمحاجبة المحاجب والمتحد والمتحرين والمراجع والاحترار والمراجع والاحترار والمراجع

. .....

	<b>5</b> . Ex Do	MIXED A ample #1: T these steps	RITHMET	'IC 23 x (−4) ÷ (−6) = display will be
	a.	Touch C	twice	• • • • • • • • • • • • • • • • • • •
	b.	Enter 23		
	Ç.	Touch X		
	d.	Enter 4		Ц.
•	e.	Touch =		
• • •	t.	Touch -		
	g.	Touch 👄		
	ħ.	Enter 6		S.
	i.	Touch 🚍		15.333333
	j.	Touch	Answer	15.333333
	Ex To	ample #2: calculate	<u>(9 + 6 - 5)</u>	<u>x 8</u> - 8 =
	Do	these steps	20	display will be
	a.	Touch C	twice	0.
	b.	Enter 9		9.
	C.	Touch +		
	d.	Enter 6		

.

.

.

•.

۰,

•

• .

· •

and the second second second second second

-

é,

5

0

495

•-



#### 6. EXPONENTS

.

Example #1: To calculate  $(3)^5 =$ Do these steps display will be

المترجع فالمتحد والمحرو فكرور كمرود فبترجع والمترا



- - - -

Ţ. Q. 

11

.

.

.

.

f. Touch =	
------------	--

g.	Touch	
----	-------	--

•

•

. . .

÷ .

.



· . · ·	1999 - 19
	1. A

#### 7. OVERFLOW INTERPRETATION

The overflow indicator "[" will appear when the display capacity of the Calculator is exceeded.

For example, multiplication of 12345678  $\times$  345678 = 4267629279684 will give the following display

142676292

.

والمادم والمحاجب فالمناجعة بوالتحاوي والارتجاج بالمتاركين

-

The "[" symbol indicates "overflow", or an answer of more than the 8 digits shown. The 8 most significant digits are displayed.

Use the key once to clear the overflow. Calculations can then continue with the displayed digits. Operation of the key again will clear the answer.

.

.

#### 8. REPEATED ADDITION

Example #1:

To calculate 6 + 3 + 3 + 3 = 15Do these steps displa

a. Touch C twice
b. Enter 6
c. Touch 4
d. Enter 3
e. Touch 4
f. Touch 4
g. Touch 4
Answer



9. PERCENTAGE

Example #1: To calculate 5% of 125 = Do these steps display will be



۹.

.

	Example #2: Add 5% tax to \$17.20 Do these steps	display will be
	a. Touch C twice	0. j
	b. Enter 17.20	17.20
	c. Touch X	17.20
	d. Enter 5	and a second se
	e. Touch %	0.86
•	f. Touch 🕂 Answei	78.06
	Example #3: Take 7% discount from \$ Do these steps	<b>14.00</b> display will be
	a. Touch C twice	
• •	b. Enter 14	
	c. Touch X	Ĩ.
	d. Enter 7	
	e. Touch <u>%</u>	86.0

<b>10.</b> When adding and with a fixed decimal pl will hold that decimal p	subtracting figures lace this calculator lace.
Example #1	
The articles just 2.05, 3.00, 2.50 an credit of \$1.00. H bill be?	d there is a return low much will the
Do these steps	display will be
a. Touch c	0.
b. Enter 3.95	3.95
c. Touch +	3.95
d. Enter 2.05	2.05
e, Touch +	6.00
f. Enter 3	3.
g. Touch 🕂	9.00
h. Enter 2.5	2.5
i. Touch +	11.50
j. Enter 1	
k. Touch - Answer	70.50

. De services de la company d

.

.

2

.

.

2

.

ţ

#### --Notes on your special calculation • • . . • . . --· . . --. - -. -· · • • . . . . . -

Reconcerns and the second second .

المناج والمعادين والمناجع والمتحج والمحاف المحافين والمراويات

#### SPECIFICATIONS

-

. 5

-

.

.

.

.

-

.

 $\sim 10^{-10}$ 

Decimal Point:	Full floating decimal point,
Capacity:	Addition, subtraction, multiplica- tion, division, percentage and omni-constant: 8 digits in / 8 digits out.
Functions:	General add, subtract, multiply, divide and percent. Chain multipli- cation and division. Mixed arithmetic. Constant multiplication and division. Exponents, fractions, reciprocals.
Power:	A.C. operation — 110/120V, 60 Hz. Battery operation — NiCd Batteries (3) 5 hour operation 7 hour charge.
Main Elements:	Large scale integrated circuit.
Supplementary Elements:	Mos ICs, Transistors, Diodes.
Dimensions:	Height 11/4", Width 3", Depth 53/4".
Weight:	9 oz.
Peripherals:	Charger/Power Supply, Vinyl Pouch, Instruction Book.

.

L

Copyright 1973

Printed in U.S.A.

.

-

.

والمعادية والمعالم الم

2