

OPERATING MANUAL

- Operation : Turn on the power slide switch.
- Clear : To clear the display, press the **C** key once.
 To clear a last entry error, press the **CE** key once.
- To change sign : To change the sign of a number, press the **CS** key. It changes the sign of a number from its original.
- To store memory : Press the **M+** key to get a number positively stored in memory and the **M-** key to get a number negatively stored in memory.
- To recall memory : Press the **MR** key to recall the stored memory. If a positive memory and a negative memory are stored, it gives the computed value of the memory.
- To clear memory : Press the **MC** key once.

Examples	:	Press Key	Answer
24 + 16		24 + 16 =	40
24 - 16		24 - 16 =	8
24 + 16 - 10		24 + 16 - 10 =	30
2.4 x 3		2.4 x 3 =	7.2
2.4 ÷ 3		2.4 ÷ 3 =	0.8
2 ²		2 x =	4
2 ³		2 x = =	8
200 x 4%		200 x 4% =	8
200 + 4%		200 + 4% =	208
200 - 4%		200 - 4% =	192
2 + 5		2 + 5 =	7
6 + 5		6 + 5 =	11
8 + 5		8 + 5 =	13
6 x 5		5 x 6 =	30
3 x 5		3 x 5 =	15
9 x 5		9 x 5 =	45
25 ÷ 5		25 ÷ 5 =	5
37 ÷ 5		37 ÷ 5 =	7.4
48 ÷ 5		48 ÷ 5 =	9.6
(5 x 6) - (2 x 3)		5 x 6 = M+ 2 x 3 = M- MR	24