

operating instructions

Portable Electronic Display Calculator



operating controls



Power switch




AC provides operation and battery charging simultaneously. DC provides portable operation only. For optimum battery charging, use • (or off position). Touch the C key to clear calculator, after || 4156turning it on.

10-key keyboard

Enter numbers as you would write them. Negative values are displayed with a negative symbol.

Clear key




Clears an erroneous keyboard entry or an operation in progress.


If an incorrect digit entry is made in the first factor of a calculation, depress C enter the correct digits and continue.

If an incorrect digit entry is made in any factor except the first factor in a calculation, depress C, then depress the previous control key again $(+ - \times \text{ or } \div)$, enter the correct digits, and continue.

© 1972 Litton Business Systems, Inc. All Rights Reserved




Plus key



Prepares the calculator to add algebraically the next entry to the previous entry or result.

Minus key




Prepares the calculator to subtract algebraically the next entry from the previous entry or result.

Multiplication key



Enters the number in the display as a multiplicand and prepares the calculator to multiply it by the next entry.

Division key



Enters the number in the display as a dividend and prepares the calculator to divide it by the next entry.

Equals key




Completes any calculation.

K key



Enter the number to be used as a constant and depress The constant factor can be an addend, subtrahend, multiplier, or divisor.



EXAMPLES AND INSTRUCTIONS

	Enter	Depress	Read		Enter	Depress	Read
ultifactor calculations				Raising to a power			
$\frac{(1+2)4-5}{6} = 1.1666666$	1	+	1.0000000	$3^3 = 27.000000$	3		3.000000
	2		3.0000000			×	9.000000
	4		12.000000				27.00000
	5		7.0000000		<u> </u>		
	6		1.1666666	Reverse sequence		C	
				operation	2	+	2.000000
onstant factors				$\frac{1234}{(2+3+4)7} = 19.5873$	301	+	5.000000
	2	= K	2.0000000	(2+3+4)7	4	×	9.000000
2 is the constant $12 \times 2 = 24.000000$	12	×	24.000000		7		63.00000
	36	×	72.000000			K	63.00000
$36 \times 2 = 72.000000$ $15 \div 2 = 7.5000000$	15		7.5000000		1234	-	19.58730
$8 \div 2 = 4.0000000$	8		4.0000000			······································	
6 + 2 = 8.0000000	6	+	8.0000000		ፕኮ _ሮ	Monroe Mod	del 20 one:
12 - 2 = 10.000000	12		10.000000	with the true algebraic displayed. For negative	sign. Fo e values a	r positive va a minus sym	alues no si
Depress C to terminate a constant to further calculation, depre	mode o	of operation	in is required	the left of the most sign Dec maximum decimal acc the Model 20.	imal inpu	t/output is c	lesigned to king capac

Should an incorrect function key be used, depress the correct function key and proceed.

Charging the Battery

When the Monroe Model 20 approaches discharge, the display will flicker and then blank. No erroneous calculation will result when the batteries approach dis-charge. The flickering dis-play is your sign to recharge the batteries.


BC-5 Charger

To charge the 20, plug the BC-5 Battery Charger into the calculator (upper left side) and an AC outlet. It will reach full charge in five to seven hours with the power switch in the . or AC position.


BC-6 Multivoltage Charger

The BC-6 charger can be used on either 117 or 234 volts by moving the voltage switch to the appropriate position. To do this:

- Loosen the four corner screws
- Carefully pull charger apart approximately 1 cm
- Using a screwdriver, move switch to desired position Close charger and retighten the four screws.
- This tightening must be done before connecting the charger to an outlet to avoid damaging the charger. If the plug on the BC-6 charger does not fit your wall outlet, purchase an adapter from a local supplier.



The lamp on the charger indicates that the batteries are being charged.






EXAMPLES AND INSTRUCTIONS

Read Depress Enter **Addition and Subtraction** 12.3 12.300000 12.3 +17.617.6 29.900000 **-4.1** 25.800000 4.1 25.800000 Multiplication × 12.500000 $12.5 \times 4.7 = 58.750000$ 12.5 58.750000 4.7 Division 5 5.0000000 $5 \div 8 = 0.6250000$ 0.6250000 continued MONROE Litton

Service for your
Model 20 is available
at any of the 365
nationwide Monroe offices.
Consult the telephone
directory yellow pages
under Adding and
Calculating Machines for
the nearest office.






Monroe, The Calculator Company

Orange, New Jersey, U.S.A. • Toronto, Canada • Zurich, Switzerland
Sales and Service Throughout the World

1607-S Rev. Printed in U.S.A.

SPECIAL OPERATING TECHNIQUES



Exponential capability Although the Model 20 has an eight-significant-digit operating capacity, it offers a true decimal and whole number capacity of $1.00000000 \times 10^{-20}$ to $9.99999999 \times 10^{+79}$.

Whole numbers If a whole number entry or result exceeds the eight-digit capacity, no decimal point will be displayed. The first eight whole numbers will be displayed, but the true accuracy of the decimal point position will be maintained internally by means of a power of tens exponent. Once a whole number result is obtained in which no decimal point is displayed, determine the decimal position by dividing the result by powers of ten until the decimal point appears.

For example:

Enter	Depress	Read
12345678	×	12345678.
54321		67062957
10000		67062957.

Dividing by 10000 caused the decimal to be displayed to the right of the least significant digit of the result; therefore, the true decimal point was actually four places to the right of the least significant digit.

Fractional numbers If a fractional number entry is made in excess of the eight-digit operating capacity, the decimal point will stop advancing

continued

operating techniques - continued

at the seventh digit position, but entry can continue until a significant digit has reached the eight-digit position. Although the decimal point will continue to be displayed at the seventh position, the true accuracy of the decimal point position will be maintained internally as in the previous whole number example.

When a fractional number result is obtained, the true position of the decimal point will be displayed. If few or no significant digits are displayed, a full eight may be recalled and their relationship to the decimal point maintained by multiplying the result by powers of ten until the desired number of significant digits is displayed. For example:

Enter	Depress	Read
7		00000001
		1.0000000
81000006		81000006
		0.0000000
	×	0.0000000
10000000		10000000
		0.1234567

Multiplying by 10000000 caused the accurate significant digits to be displayed, with the decimal point to the left of the most significant digit, therefore, there are seven zeros separating the first significant digit from the decimal point.



Monroe, The Calculator Company

Orange, New Jersey, U.S.A. • Toronto, Canada • Zurich, Switzerland Sales and Service Throughout the World

© 1972 Litton Business Systems, Inc. • All Rights Reserved

1646-S

Printed in U.S.A.